


編號/名稱	圖片	價格	編號/名稱	圖片	價格
3899-001 車面		元/個 (含前燈 2 粒) (需噴漆)	3899-002 車底		元/個 (含電池蓋和螺絲) (需噴漆)
3899-003 炮塔面		元/個 (含子彈倉) (需噴漆)	3899-004 炮管		元/條 (不含鉛管) (需噴漆)
3899-005 炮塔底		元/個	3899-006 炮管座		元/個 (需噴漆)
3899-007 BB 彈彈道		元/個	3899-008 冒煙管連接件		元/對 (每對含左右各 1 個)
3899-009 主輪 (外)		元/套 (每套含 12 個) (需噴漆)	3899-010 主輪 (內)		元/套 (每套含 12 個)
3899-011 長負重輪 (內) 及負重輪 (外)		元/套 (每套各含 1 個)	3899-012 短負重輪 (內) 及負重輪 (外)		元/套 (每套各含 1 個)
3899-013 主輪中心罩		元/片 (每片含主輪罩 6 個) (需噴漆)	3899-014 驅動輪		元/對 (需噴漆)
3899-015 誘導輪		元/對 (含螺絲及銅套) (需噴漆)	3899-016 塑膠履帶 (尼龍)		元/對

編號/名稱	圖片	價格	編號/名稱	圖片	價格
3899-017 主輪搖臂		元/套 每套 12 個	3899-018 子彈倉		元/個
3899-019 補給窗窗蓋		元/個 (需噴漆)	3899-020 主機板固定座		元/塊
3899-021 車底電池槽缺口件		元/塊	3899-022 螺母固定件		元/個
3899-023 轉向大齒輪 2		元/個	3899-024 鐳射鐳射裝置轉動盤		元/個 (需噴漆)
3899-025 車面前燈模		元/模 (需噴漆)	3899-026 鐳射裝置配件模		元/模 (需噴漆)
			3899-028 工具模 2		元/模 (需噴漆)
3899-029 工具模 3		元/模 (含後燈燈板) (需噴漆)	3899-030 工具模 4		元/模 (需噴漆)
3899-031 工具模 5		元/模 (噴啞黑色)	3899-032 工具模 6		元/模 (需噴漆)

編號/名稱	圖片	價格	編號/名稱	圖片	價格
3899-033 履帶限位片		元/個 (需噴漆與驅動輪同種顏色)	3899-034 車底晶震座		元/個 (需噴漆)
3899-035 車面左壓板		元/模 (需噴漆)	3899-036 電池蓋		5.0元/個 (含3*9機絲和螺絲PVC墊各一個) (需噴漆)
3899-037 車面右壓板		元/條 (需噴漆)	3899-038 彩盒提手		元/套 (一套各1個)
3899-039 車底防撞板		元/塊 (需噴漆)	3899-040 車底後板		元/塊 (需噴漆)
3899-041 車面工具箱		元/個 (需噴漆)	3899-042 車面V型壓條		元/條 (需噴漆)
3899-043 子彈倉蓋組件		元/套 (每套各含1個需噴漆)	3899-044 槍手倉蓋組件		元/套 (每套各含1個需噴漆)
3899-045 炮塔保護網(左)		元/塊 (需噴漆)	3899-046 炮塔保護網(右)		元/塊 (需噴漆)
3899-047 車面前端附加裝甲板		元/塊 (需噴漆)	3899-048 炮塔左前端附加裝甲板		元/塊 (需噴漆)

編號/名稱	圖片	價格	編號/名稱	圖片	價格
3899-049 炮塔右前 端附加裝 甲板		元/塊 (需噴漆)	3899-050 炮塔左側 裝附加甲 板		元/塊 (需噴漆)
3899-051 炮塔右側 附加裝甲 板		元/塊 (需噴漆)	3899-052 炮塔側面 附加甲板		元/對 (含 2 片) (需噴漆)
3899-053 附加裝甲 炮塔面		元/個 (含子彈倉) (需噴漆)	3899-054 附加裝甲 車面		元/套 (含前燈和前 燈) (需噴漆)
3899-060 冒煙管		元/套 (每套各含 1 條 110mm 和 1 條 10mm)	3899-065 車面後燈 燈左右燈 板		元/套 (每套含 3mm 燈 3 只 連接板一塊)
3899-066 雙向小 2P 插頭線		69 元/條 (用於尾燈)	3899-078 減震扭 簧		元/套 (每套共 12 條, 編號 C3295/3294)
3899-079 金屬誘導 輪 (鋅合金)		元/套 (每套含 2 個 和 2*6 螺絲 6 粒)	3899-080 金屬履 帶 (鋅合 金)		元/對
3899-081 金屬驅動 輪 (鋅合金)		元/對	3899-090 說明書		元/本

編號/名稱	圖片	價格	編號/名稱	圖片	價格
3899-091 貼紙		元/張	3899-093 炮塔連車面 (BB 彈發射)		元/套 (含車面炮 管升降 BB 彈波箱等)
3899-094 帶輪車底		元/套 (含主輪內外 以及主輪搖 臂. 減震. 螺絲. 等 部件)	3899-095 炮管連炮塔 (BB 彈發射)		元/套 (含 BB 彈波 箱炮管等配 件)
3899-096 鋁管 (L:278mm)		元/條 (鑽好孔位)			